



U-Ground & U-Ground OEM Manual

V 2.02

2020/09/01



Table of Contents

1	Foreword.....	3
2	General System Introduction.....	4
2.1	Concept of system operation.....	5
3	U-Ground.....	6
3.1	U-Ground and U-Ground OEM.....	6
3.1.1	Identifying B10 based units.....	6
3.1.1.1	OEM.....	6
3.1.1.2	Boxed.....	6
3.2	Power supply.....	6
3.3	U-Ground Connections.....	7
3.3.1	U- Ground Main Connector.....	7
3.3.2	Pressure sensors connections.....	10
3.3.2.1	U-Ground (Box) pressure connections.....	10
3.3.2.2	U-Ground OEM pressure connections.....	10
3.3.3	Radio-link antenna connections.....	10
3.3.3.1	U-Ground (Box) Radio-link connection.....	10
3.3.3.2	U-Ground OEM Radio-link connection.....	10
3.3.4	External Radio-link connection.....	10
3.3.5	GPS antenna connections.....	11
3.3.5.1	U-Ground (Box) GPS connection.....	11
3.3.5.2	U-Ground OEM GPS connection.....	11
4	Communications.....	12
5	Alarms.....	13
5.1	Audible Signal.....	13
6	Joystick.....	15
6.1	Connecting the Joystick to the Main connector.....	16
6.2	Configuration for Futaba Joystick.....	17
Appendix A	Box Mechanical Drawing.....	18
Appendix B	OEM Mechanical Drawing.....	19
Appendix C	Changelog.....	20

1 Foreword

This manual applies to autopilots produced from September 1st 2020 and based around the B10 (Board 10).

Please, notice that while the mechanical aspects of the autopilot have been kept equal, the electrical connections are different across hardware version. *Damage to the hardware may occur if these differences are not checked.*

If you don't know if your autopilot is B10 based check section Identifying B10 based units 3.1.1 on page 6

Previous versions of this manual are available from Airelectronics. For older autopilots (B09, B08, B07, B04) contact us via email (info@airelectronics.es) to get proper document describing your hardware

2 General System Introduction

Airelectronics has developed a complete solution for both rotary and fixed wing UAVs. The system is composed of:

- U-Pilot or U-Pilot OEM
- U-Ground or U-Ground OEM
- U-See Software

U-Pilot manages and controls the vehicle from Take-off to Landing, being capable of controlling any kind of aircraft including fixed wing, helicopters and multicopters.

U-Pilot is completely capable of following a flight plan with up to 200 real-time editable points. Once the flight plan is loaded on U-Pilot, it is independent of operator instructions, and in case of a communications failure, U-Pilot starts a Return Home and Land manoeuvre which would safely land the UAV on the Runway Point.

Thanks to its versatility, U-Pilot can control any payload on board the UAV such as cameras, parachutes or sensors. These devices can be real time controlled by a computer operator or by U-Pilot automatically.

The FPGA technology used in U-Pilot and U-Ground allows the system to have several logic working in parallel with the main processors. U-Pilot has working in parallel:

- Up to 26 PWM (Pulse-Width Modulation) or GPIO (General Purpose Input / Output).
- 3 ADC inputs (Analogical Digital Converter) to monitor the voltages of 3 batteries on the UAV.
- Up to 8 serial ports RS232 (configurable to RS485)¹ to communicate with payloads, external magnetometers, etc.
- A radio with up to 100 km²
- GPS with RTK capability³, dynamic and static pressure sensors, a magnetometer, gyroscopes and accelerometers.

U-Pilot is built using a two parallel microprocessor approach:

- One processor handling the state estimation and control of the UAV, using hardware acceleration to calculate high speed algorithms.
- A second processor handles of the mission at high level, communications with U-Ground and the Payload.
- The processors do not spend time handling low-level tasks, as these tasks are processed in parallel by dedicated logic of the FPGA.

Due to the fact that those two processors are working in parallel and there is dedicated electronics processing the serial ports, sensors, inputs and outputs, the system is capable of recalculating its position, orientation and closing control loops at 1000 Hz. This control speed provides a great navigation accuracy and control.

On the ground segment, Airelectronics has both U-Ground and U-See.

U-Ground is a ground station that mainly acts as a relay of command and data between U-Pilot and U-See software. Besides acting as data relay, U-Ground provides useful information to U-

¹ There are several options for these ports. Please, contact Airelectronics in order to know the possible configurations.

² Range may vary with the frequency band used. Default is 900 MHz but legal limitations in some countries may change this.

³ Disabled by default. Contact Airelectronics to acquire this capability.

Pilot such as U-Ground position and pressures. U-Ground hardware is also capable of handling a Antenna tracking system.

U-See software is a user friendly program that runs in any personal computer running Windows or Linux.

Using U-See, the UAV operator can monitor the current state of the vehicle, control the UAV or modify the vehicle mission in real time.

2.1 Concept of system operation

The system consists of a U-Pilot installed on an aircraft connected to a U-Ground through a radio link. (See figure 1 attached below)

U-Ground has its own radio link to communicate with the U-Pilot and a RS-232 port to relay the data and command between a PC running U-See and the U-Pilot on-board the vehicle.

Under certain circumstances such as aircraft integration and characterization, a Futaba Emitter is recommended in order to provide manual override of the vehicle.




Figure 1: System concept

The mission operation team is usually formed by two people:

- An External Pilot who will handle the Futaba Joystick in case a manual control of the UAV is desired (specially during the development and adjustment phase).
- A U-See operator that will command the mission using a computer.

When using the UAV for surveillance purposes, a camera operator is recommended.

3 U-Ground

The U-Ground hardware is the link between our U-Pilot and the computer running U-See that finally controls the mission.

U-Ground hardware relays the data it receives from the U-Pilot through a serial interface. This data is processed in U-See running on a standard PC which should have a port available (We include a USB to RS-232 converter in the installation kit).

U-Ground has an integrated GPS to track its own position and standard PWM outputs to allow the steering of directional antennas towards the UAV to maintain a stable video link.

It also provides the manual override function, by connecting any standard Futaba transmitter with a trainer port to the hardware. In that way, an external pilot can fly the UAV in a manual mode (Refer to section 6, joystick) with the very familiar interface of a Futaba joystick, while keeping all its functionality (exponential settings in control, mixtures, etc.)

3.1 U-Ground and U-Ground OEM

U-Ground can be acquired in two versions, the standard version, enclosed in an aluminium box, and the OEM version that is not enclosed, ready to be embedded into the customer system.

Unless told otherwise, the explanations provided by this document are valid for both versions. When different explanations are required, this document will state it.

3.1.1 Identifying B10 based units

The ground station is built around a basic electronics board that change with incremental designs. Current design is based around the B10 (Board 10, 10th iteration of the design) and **the contents of this manual are only applicable to u-grounds based on a B10**

The mechanical design of the autopilot has been kept from previous iteration (B09) but the functional and electrical levels of the main connector pinout have been changed so previous designs and current one are not directly interchangeable.

3.1.1.1 OEM

The PCB silkscreen has printed, between the pressure sensors" U-Pilot B10 SNXXX where SN is the serial number of the particular board.

3.1.1.2 Boxed

If the autopilot is B10 based the top left corner of the lid in the autopilot will have a mechanical notch painted in blue besides de "Radio" text engraving.

3.2 Power supply

U-Ground power supply accepts voltages in a range from 6.0V to 24V.

CAUTION: Powering U-Ground at a voltage OUT of range can cause IRREVERSIBLE DAMAGE to the system. Please read carefully this manual and do not hesitate to contact us (www.airelectronics.es) if needed.

Typical power consumption about 4 Watt, but the power system should be prepared to withstand 7 Watts peaks. This consumption will mean an intensity consumption of 0.8 Amp. at 6V or 0.4 Amp. at 12 V.

3.3 U-Ground Connections

This section provides the required information about U- Ground connections, including:

- Main connector connections
- Pressure connections
- Radio-Link connections
- GPS antenna connections.

3.3.1 U- Ground Main Connector

The aerial part of connector used for U-Ground is provided in the Installation Kit. Cables in the aerial connector are colour coded. The following table describes the function of every pin in the main connector in U-Ground and the corresponding colour coded cable in the supplied aerial connector.

NOTE: Please, take into account than in these tables, Tx and Rx suffix are referred to U-Ground. This is: a line marked as “Comms Rx” is the pin dedicated to receive data from the radio, and thus, must be connected to the sending pin in the radio connector.

NOTE: This pinout reflects the default configuration for 8 serial ports RS232. For another serial ports option, **pins 7, 8, 11, 12, 15, 23, 25 and 26 could change functionality and voltage levels**, so be careful because an error in the connection could cause a permanent damage on the U-Pilot. Contact Airelectronics for obtaining the suitable pinout table.




Figure 2: Main connector on U-Ground as seen from the front.

PIN	I/O	Function	Cable Colour
1	In	ADC 2	Black
2	In	ADC 1	Brown
3	DC in	V _{IN}	Red
4	GND	Ground	Orange
5	In	External DataLink RX	Yellow
6	Out	External DataLink TX	Green
7	Out	RS232 Port 6 Tx	Blue
8	Out	RS232 Port 7 Tx	Purple
9	In	DGPS-RS232 Levels Correction	Grey
10	Out	Reserved	White
11	Out	RS232 Port 5 Tx	Black
12	In	RS232 Port 5 Rx	Brown
13	Out	Second External DataLink TX (Satcom)	Red
14	In	Second External DataLink RX (Satcom)	Orange
15	In	RS232 Port 7 Rx	Yellow
16	In	Antenna Tracker RX	Green
17	Out	RS232 comms Tx (PC)	Blue
18	In	RS232 comms Rx (PC)	Purple
19	In	ADC 3	Grey
20	DC out	Futaba Joystick Supply	White
21	Out	Tracker Pan Servo	Black
22	Out	Tracker Tilt Servo	Brown
23	In	RS232 Port 6 Rx	Red
24	Out	Reserved	Orange
25	Out	RS232 Port 8 Tx	Yellow
26	In	Futaba Joystick Signal	Green
27	In	Buzzer	Blue
28	Out	Antenna Tracker TX	Purple
29	Out	External Radio Link RSSI Line (Digital 3.3V TTL)	Grey
30	Out	Reserved	White
31	Out	Reserved	Black
32	Out	Reserved	Brown
33	Out	Reserved	Red
34	Out	Reserved	Orange
35	In	RS232 Port 8 Rx	Yellow
36	GND	Ground	Green
37	Out	Square Wave Audible Signal	Blue
38	Out	Alarm 1	Purple
39	Out	Alarm 2	Grey
40	Out	Alarm 3	White
41	Out	Alarm 4	Black
42	Out	Alarm 5	Brown
43	Out	Alarm 6	Red
44	Out	Alarm 7	Orange
45	Out	Reserved	Yellow
46	Out	Reserved	Green
47	Out	Reserved	Blue
48	Out	Reserved	Purple
49	Out	Reserved	Grey
50	Out	Reserved	White
51	DC Out	External radiolink power supply	Black

Note: At least one GND has to be connected to ground, the other GND pins are optional. All the GND pins are connected internally between them.

Note: Only one of the available DGPS inputs should be connected (Pin 9 or 24)

3.3.2 Pressure sensors connections


U-Ground has a single static pressure sensor. The static pressure tap may be left unconnected if U-Ground environment is not sealed or pressurized. Otherwise it must be connected to the ambient pressure.

The static pressure connection installation differs in U-Ground and U-Ground OEM. Depending on your U-Ground version, you have to refer to the appropriate subsection.

3.3.2.1 U-Ground (Box) pressure connections

U-Pilot pressure connection is properly labelled on the front face of the box with the name "STATIC". The static pressure sensor can be left unconnected if U-Pilot environment is not pressurized or sealed.

3.3.2.2 U-Ground OEM pressure connections



Static

The OEM version of U-Ground exposes directly the static pressure sensors. The sensor can be identified with the attached image.

The static pressure sensor can be left unconnected if U-Pilot environment is not pressurized or sealed.

Figure 3: Static pressure sensor

3.3.3 Radio-link antenna connections

The radio-link antenna connection depends on the version of U-Ground. Depending on your U-Ground version, please refer to the appropriate subsection.

3.3.3.1 U-Ground (Box) Radio-link connection

The radio-link antenna must be connected to U-Ground with an SMA-connector to the connector labelled as "RADIO" in the front face of U- Ground box.

3.3.3.2 U-Ground OEM Radio-link connection

The radio-link antenna must be connected to the radio-module using and MMCX connector as described in the mechanical drawing appendix.

3.3.4 External Radio-link connection

If the U-Ground doesn't have an internal radio-link module, the U-Ground box will have a 5-pin connector in order to manage an external radio-link power supply and communications instead of SMA connector. Airelectronics offers a harness for the U-Ground and U-Radiolink connection using this connector.

The pinout is shown below:




Figure 4: External radiolink connector on U-Pilot as seen from the front if internal radio module is not included

PIN	I/O	Function
1	In	Radio Diagnostics Rx
2	Out	Radio Data Tx
3	In	Radio Data Rx
4	V _{Out}	V _{Out} (5V)
5	Ground	Ground

NOTE: Take into account than in the table, Tx and Rx suffix are referred to U-Ground.

In this case, a clearance distance of 45mm is required at the front of the U-Ground box because of the aerial connector.

3.3.5 GPS antenna connections

The GPS antenna installation depends on the version of U-Ground. Depending on your U-Ground version, please refer to the appropriate subsection.

3.3.5.1 U-Ground (Box) GPS connection

The GPS antenna must be connected to U-Ground with an SMA-connector to the connector labelled as “GPS” in the front face of U-Ground box.

3.3.5.2 U-Ground OEM GPS connection

U-Ground OEM has two GPS exposed connectors:

- UFL connector.
- SMA connector.

The GPS antenna can be connected to any of the two connectors using the appropriate connector but NOT BOTH simultaneously. The location of the UFL and SMA connectors is described in the mechanical drawings for the OEM version.

If the U-Pilot has the RTK capability active, an L1/L2 active antenna should be connected. Contact Airelectronics to be supplied with a suitable antenna.

4 Communications

Communication between the U-Pilot and the U-Ground is done by a Radio Link with High noise immunity, high reliability and a range up to 100 km.

All the settings regarding the radio configuration are configured by Airelectronics when the units are produced, so you do not have to worry about the communications, it is completely plug and play.

Available on the bands of 2,4 GHz, 1,4 Ghz, 900 MHz , 455 MHz and 869 MHz with channel hopping.

In case you wish to use your own radio link, Airelectronics can supply you with a version of U-Pilot without a radio on board.

The data transmitted from the U-Pilot unit is then relayed to a computer through a RS-232 interface. The computer used must have an available RS-232 port or use a serial USB to RS-232 converter. This data is to be interpreted and presented to the end user through our U-See software.

5 Alarms

When communications between U-Pilot and U-Ground are active, the latter will decode the downlink communications and present basic information through the activation of the Alarms lines.

These lines are designed to give a 3.3V TTL signal of high when the alarm is active and low when the signal is not toggled. The maximum signal strength the U-Ground is capable of driving is 25 mA.

Typical use of these signal is the usage of LEDs or other kind of visual aids. If the required load is expected to consume more than 25 mA, a MOSFET drive is mandatory to avoid circuit damage.

The meaning of every alarm is detailed in the following table

Alarm	Active when:
Alarm 1	COMMs quality level is below 70%
Alarm 2	Some voltage is below the configured value for an alarm.
Alarm 3	Distance is above the configured threshold for alarm
Alarm 4	Autopilot has risen an alarm that is neither Distance or Voltage related. This includes: <ul style="list-style-type: none"> • GPS Alarm • Gyro Alarm • ACC Alarm • PS Alarm • Qd Alarm when communicating with a fixed wing vehicle • Joystick Alarm • Magnetometer Alarm when communicating with a rotary wing vehicle • Joystick Alarms
Alarm 5	System is ready for flight. In fixed wing system this indicates: <ul style="list-style-type: none"> • No voltage or distance related alarms triggered • 3D GPS Fix with 6 satellites • At least once since the autopilot has been communicated the dynamic sensor was seen to indicate above 2.5 m/s • No autopilot alarm risen (except magnetometer) In rotary wing this indicates: <ul style="list-style-type: none"> • No voltage or distance related alarms triggered • 3D GPS Fix with at least 6 satellites • Magnetometer is online and magnetic module is within expected value • No autopilot alarm risen (except dynamic sensor)
Alarm 6	System wants to return home. This alarm will be triggered whenever a mission supervisor limit has been surpassed at anytime in the past. As the user can choose to over-command the automatic return home feature, this alarm will remain triggered to remember the need to return home.
Alarm 7	System is executing an automatic Return and Home manoeuvre.

Airelectronics could have tailored your set of alarms for your project. So, please, check for extra documentation Airelectronics could have transferred to you. In case of doubt. Contact info@airelectronics.es.

5.1 Audible Signal

Besides toggling the corresponding line, the ground station will generate a square wave to be feed into a square wave buzzer.

The audible tone generated at the time of writing (2014/09/03) are 3 beeps of half a second duration and variable pitch in function of the toggled alarm.

An audible tone will be generated any time an alarms goes from deactivated to active. If more than one alarm is triggered at the same time, the ground station will generate tones for every one of the alarms in a sequential manner.

Audible tone is designed to be used as an addition to a visual feedback mechanism: Audible tone attracts the attention of the operator and he checks the visual feedback panel.

Again, U-Ground will drive at most 25 mA at 3.3V TTL. As this is usually too weak to drive a buzzer with enough power to be clearly audible, a MOSFET drive would be recommended for the buzzer.

6 Joystick

The Futaba joystick must be connected to U-Ground through the U-Ground harness using the 3-way military connector.

The Joystick used on the system is manufactured by Futaba. Airelectronics serves a modified version of the model T6J ready to be connected to the 3-way military connector and with its own power regulator, so recharging the batteries is not required⁴. The pin connection to the ground Hardware is detailed on [U-Ground Connections](#).



Figure 5: Joystick

The following table details the functionality of the Futaba Joystick.

STICK or SWITCH in FUTABA JOYSTICK	Mapping in Futaba T7CP	Mapping in Futaba T6J
Aileron command	Right Stick. Left/Right	Right Stick. Left/Right
Elevator Command	Right Stick. Up/Down	Right Stick. Up/Down
Rudder command	Left Stick. Left/Right	Left Stick. Left/Right
Throttle command	Left Stick. Up/Down	Left Stick. Up/Down
Manual override request (used as a digital switch)	Switch B.	Switch A
Roll command during Roulette mode	Wheel VR	Wheel VR
Camera Shooter ⁵ (used as a digital switch)	Switch D	Switch B

Table 1: Channel usage and usual mapping in Futaba joystick

- 4 Some customers may be still in possession of an older model of the emitter (Futaba T7CP). In that case, recharging batteries is still needed. Configurations and use of the T7CP model are still described in this manual.
- 5 The autopilot has a PWM output reserved to be connected to the shutter of a camera to allow you to take pictures at any time you want. This is referred in the manuals as “camera shooter”.

6.1 Connecting the Joystick to the Main connector

To connect the Futaba emitter to U-Ground , a manufactured harness is usually served with the U-Ground installation kit. If the customer needs to manufacture a custom harness, the pin-out of the Futaba connector is described in this section.



Using the supplied aerial military connector, the connections between U-Ground and Futaba military connector (as detailed in Figure 6) should be established as shown in following table (Table 2)

Pin in Futaba Connector	Function	Connect to
A	Signal	Pin 26 (Green)
B	Vin	Pin 20 (White)
C	GND	Pin 4 or 36

Table 2: Futaba connections




Figure 6: Military connector in Airelectronics' modified Futaba

WARNING: Futaba Joystick must not be hot plugged. Please, make sure U-Ground is not powered before plugging the Futaba Joystick connector.









6.2 Configuration for Futaba Joystick

Airelectronics supplies a Futaba emitter ready to be plugged to U-Ground. Configuration should be not altered for the proper operation of the system.


For reference, we include hereby the proper configuration for a Futaba:

Feature	Proper Setting (T7CP)	Proper Setting (T6J)
Modulation	PCM/PPM (depends on model)	N/A
Channel 5 switch	Switch D	N/A
Channel 7 switch	Switch B	N/A
Sub-Trim	All set to 0	All set to 0
Dual Rates	100%	N/A
Exponential	0%	0%
End points	100%	100%
Reverse	Normal for all channels	Normal for all channels
Throttle-cut	Inhibited	Inhibited
Fail-safe	Normal in all channels	Normal in all channels

Modulation must be set to PCM in Futaba T7CP variant to work with U-Ground. In case you need to adjust modulation, follow the following instructions




Open Basic menu, then open PARAMETER.	MODE for 1 second. (If ADVANCE , MODE again.)  or  to PARAMETER 
Go to MODUL and change setting.	  to MODUL  to PCM . PCM flashes on screen
Close menu and cycle power.	  Power Off. Power On.

For the rest of settings, please, check the manual of the joystick.





Please, check with the software (U-See) that the joystick sticks movement correspond to the following figure (In U-See, View → Joystick).

Appendix A Box Mechanical Drawing




Airelectronics
Distances are in mm

Appendix B OEM Mechanical Drawing



All distances are in mm
A clearance distance of 3mm is required at the bottom of the board



Appendix C Changelog

This annex describes changes introduced to this document.

Date	Changes
2020/09/01	<ul style="list-style-type: none"> • Document version up to 2.02 • Solved small typos • Ready document for public release • Add a foreword to highlight this manual refers B10 hardware
2020/05/18	<ul style="list-style-type: none"> • Document version up to 2.00 • Pinout of the U-Ground changes drastically in order to reflect the new 8 serial ports lines. • In addition, DGPS-TTL corrections function is not available from now.
2020/01/16	<ul style="list-style-type: none"> • Document version up to 1.33. • Corrected error with Antenna Tracker comms pins. Now, pins 16 & 28 are used. • Pins 13 & 14 are indicated as Second External DataLink (Satcom) comms signals.
2018/06/01	<ul style="list-style-type: none"> • Version 1.32 • Added pin connections for External Radiolink connector placed on the U-Ground box if internal radio module is not included.
2017/03/14	<ul style="list-style-type: none"> • Document version up to 1.30 • Adjusted a bit the wording for the external radio link description in the pin table
2017/03/13	<ul style="list-style-type: none"> • Document version up to 1.29 • Updated connection table: Added the proper pins for the External Radio Link support. • Added port description for the External Antenna tracker controlled by RS232.
2015/07/15	<ul style="list-style-type: none"> • Document version up to 1.28 • Changed Futaba emitter connection table
2015/06/23	<ul style="list-style-type: none"> • Document version up to 1.27 • Changed pin connections for Futaba Joystick • Changed pin connections for RS232 comms Rx/Tx
2015/05/15	<ul style="list-style-type: none"> • Document version up to 1.26 • Included DGPS RS232 line documentation in connections table • In the Joystick connections diagram, changed numbers to letters to describe connector pins. These letters match on-hardware labelling and make more difficult to make a mistake.
2015/03/16	<ul style="list-style-type: none"> • Changed pin Connections for Emitter.
2015/02/23	<ul style="list-style-type: none"> • Updated version to 1.25 • Added Mechanical Drawings • Added explanation for pressure and RF connectors. • Updated description of pins to match 51 pin connector. • Updated information about the Futaba Emitter model used.
2014/09/03	<ul style="list-style-type: none"> • Version of document up to 1.24 • Added pin-out for alarm signalling • Added pin-out for audible alarm • Added description of the visible alarms • Added Changelog table